

UNIT - V:

THERMAL SENSORS



PSG College of
Technology, Coimbatore

SENSORS FOR ENGINEERING APPLICATIONS

23I202



Content of the Course – Sensors for Engineering applications 23I202

STRAIN AND PRESSURE MEASUREMENT	ELECTRONIC SENSORS	MOTION SENSORS	LIGHT SENSORS	THERMAL SENSORS
Resistance strain gauge Piezoelectric pressure sensor, characteristics Electronic circuits for strain gauge load cells Interferometer Capacitance pressure sensor	Inductive, Capacitive and ultrasonic based proximity sensors Reed switch Hall-effect switching sensors Capacitive based humidity sensor Liquid level detectors, Flow sensors Smoke sensors	Capacitor plate sensor Inductive sensors LVDT Accelerometer systems Rotation sensors Piezoelectric devices for motion sensing Hall effect-based speed sensor.	Color temperature Light flux Photo sensors, Photo resistor and photoconductors, Photodiodes, Phototransistors, Photovoltaic devices, Fiber-optic sensors (FOS): Fibre-optic pressure sensor and its applications LIDAR	Bimetallic strip, Semiconductor based Temperature sensor, Thermocouples, Resistance thermometers, Thermistors, PTC and NTC thermistors Semiconductor-based applications. Infrared sensors: bolometer, Pyroelectric detector, semiconductor based IR sensors.



CONTENTS

UNIT - V

- ☐ **Bimetallic strip**
- ☐ **Semiconductor based Temperature sensor**
- ☐ **Thermocouple**
- ☐ **Resistance thermometers**
- ☐ **Thermistors, PTC and NTC thermistors**
- ☐ **Infrared sensors: bolometer**
- ☐ **Pyroelectric detector, semiconductor based IR sensors.**

CONTENTS


UNIT - V



RTD



Thermocouple



Thermistor





Semiconductor

REALPARS

Thermal Sensors

Thermal sensors are devices designed to detect, measure, and convert thermal energy (heat) into an electrical signal or visual representation.






Thermal Properties of Materials

The following are the various thermal characteristics of Material:

1. **Temperature**
2. **Specific Heat**
3. **Heat capacity**
4. **Thermal conductivity**
5. **Melting point**
6. **Thermal diffusivity**
7. **Thermal shock resistance**

Atomic Vibrations


Atomic vibrations are in the form of lattice waves or **phonons**




- Normal lattice positions for atoms
- Positions displaced because of vibrations

Thermal Expansion

Liquids expand more when heated than solids.



Cold



Hot

Gases expand more when heated than liquids (depending upon P, V and T)

When heated, solids (and liquids and gases) gain thermal energy. The particles start to move about more – their vibrations take up more space, so there is expansion in all directions. The opposite is true when the temperature falls – the material will get smaller (contract).


Material	Coefficient of expansion
Glass	8.5
Concrete	12
Brass	19
Steel	11
Aluminium	23




Thermal Expansion

- examples

- Girders in buildings and bridges are made with gaps at the ends.
- Glass to be used in cooking has to be a low expansion type such as Pyrex otherwise it would shatter as it got hot.
- Rivets are heated before they are put in place to hold two metal plates together.



High-speed planes are warmed by air friction and so get longer.




Bridges have gaps to allow for expansion. Rollers may be used at one end so that movement can take place.

Suspended overhead cables are left slack to allow for contraction that could happen on a very cold day.

Cold day


Hot day



Thermal Expansion

- applications

Thermometer



As the temperature rises, the liquid in the bulb expands, and so rises up the narrow tube which is calibrated to fixed points (eg. 0°C, 100°C)

Calibration scale

Expanding liquid

Mercury or alcohol

Bimetallic strip

High expansion metal




Low expansion metal



Bimetallic strip when hot


In a bimetallic strip, a low expansion metal (eg. Invar) is bonded to a high expansion metal (eg. Brass). As the strip is heated, the brass expands more than the invar, causing the strip to bend.



Bimetallic strips may be used in thermostats – devices for maintaining a steady temperature, such as in water heaters.

Measuring temperature

- Examples of thermometers



Clinical thermometer.

- Measures human temperatures **very** accurately. Scale is **restricted** to a few degrees either side of the **normal body temperature** (37°C). A **restriction** in the neck stops the mercury from **dropping** until the reading is taken.



digital thermometer

Digital Clinical thermometer.

- Contains a **thermistor** inside the probe. As the temperature **rises** the thermistor becomes a much better **conductor**, causing a **higher current** to flow, and so a **higher reading** on the meter.



Heat Capacity

The ability of a material to absorb heat

- Quantitatively: The energy required to produce a unit rise in temperature for one mole of a material.

heat capacity (J/mol-K) \rightarrow $C = \frac{dQ}{dT}$

dQ ← energy input (J/mol)

dT ← temperature change (K)

- Two ways to measure heat capacity:
 C_p : Heat capacity at constant pressure.
 C_v : Heat capacity at constant volume.

$$C_p \text{ usually } > C_v$$

- Heat capacity has units of $\frac{\text{J}}{\text{mol} \cdot \text{K}} \left(\frac{\text{Btu}}{\text{lb} - \text{mol} \cdot ^\circ\text{F}} \right)$



Specific Heat: Comparison

 increasing c_p	Material	c_p (J/kg-K) at room T
	• <u>Polymers</u>	
	Polypropylene	1925
	Polyethylene	1850
	Polystyrene	1170
	Teflon	1050
	• <u>Ceramics</u>	
	Magnesia (MgO)	940
	Alumina (Al ₂ O ₃)	775
	Glass	840
	• <u>Metals</u>	
	Aluminum	900
	Steel	486
	Tungsten	138
	Gold	128


c_p (specific heat): (J/kg-K)
 C_p (heat capacity): (J/mol-K)

- Why is c_p significantly larger for polymers?



Thermal Expansion

Materials change size when temperature is changed



$$\frac{l_{\text{final}} - l_{\text{initial}}}{l_{\text{initial}}} = \alpha_l (T_{\text{final}} - T_{\text{initial}})$$

α_l linear coefficient of thermal expansion ($1/\text{K}$ or $1/^\circ\text{C}$)



Thermal Expansion: Example

Ex: A copper wire 15 m long is cooled from 40 to -9°C. How much change in length will it experience?

- Answer: For Cu $\alpha_{\ell} = 16.5 \times 10^{-6} (\text{°C})^{-1}$

rearranging Equation 19.3b

$$\Delta \ell = \alpha_{\ell} \ell_0 \Delta T = [16.5 \times 10^{-6} (1/\text{°C})](15 \text{ m})[40\text{°C} - (-9\text{°C})]$$

$$\Delta \ell = 0.012 \text{ m} = 12 \text{ mm}$$



Thermal Conductivity

The ability of a material to transport heat.

Fourier's Law

heat flux (J/m²-s) → $q = -k \frac{dT}{dx}$

temperature gradient

thermal conductivity (J/m-K-s)



- Atomic perspective: Atomic vibrations and free electrons in hotter regions transport energy to cooler regions.




Thermal Conductivity: Comparison

	Material	k (W/m-K)	Energy Transfer Mechanism
 increasing k	• <u>Metals</u>		
	Aluminum	247	atomic vibrations and motion of free electrons
	Steel	52	
	Tungsten	178	
	Gold	315	
	• <u>Ceramics</u>		
	Magnesia (MgO)	38	atomic vibrations
	Alumina (Al ₂ O ₃)	39	
	Soda-lime glass	1.7	
	Silica (cryst. SiO ₂)	1.4	
	• <u>Polymers</u>		
	Polypropylene	0.12	vibration/rotation of chain molecules
	Polyethylene	0.46-0.50	
	Polystyrene	0.13	
	Teflon	0.25	



Thermal Shock Resistance

- Occurs due to: nonuniform heating/cooling
- Ex: Assume top thin layer is rapidly cooled from T_1 to T_2



Tension develops at surface

$$\sigma = -E\alpha_{\ell}(T_1 - T_2)$$

Temperature difference that can be produced by cooling:

$$(T_1 - T_2) = \frac{\text{quench rate}}{k}$$

Critical temperature difference for fracture (set $\sigma = \sigma_f$)

$$(T_1 - T_2)_{\text{fracture}} = \frac{\sigma_f}{E\alpha_{\ell}}$$


set equal

- $(\text{quench rate})_{\text{for fracture}} = \text{Thermal Shock Resistance (TSR)} \propto \frac{\sigma_f k}{E\alpha_{\ell}}$
- Large TSR when $\frac{\sigma_f k}{E\alpha_{\ell}}$ is large

Thermal Protection System


- Application:

Space Shuttle Orbiter




, "The Shuttle Orbiter Thermal Protection System", *Ceramic Bulletin*, No. 11, Nov. 1981, p. 1189.)

- **Silica tiles** (400-1260°C):
-- large scale application



-- microstructure:



← 100 μm →

~90% porosity!
Si fibers
bonded to one
another during
heat treatment.

Fig. 19.3W, *Callister 5e*. (Fig. 19.3W courtesy the National Aeronautics and Space Administration.)




Summary

The thermal properties of materials include:

- **Heat capacity:**
 - energy required to increase a mole of material by a unit T
 - energy is stored as atomic vibrations
- **Coefficient of thermal expansion:**
 - the size of a material changes with a change in temperature
 - polymers have the largest values
- **Thermal conductivity:**
 - the ability of a material to transport heat
 - metals have the largest values
- **Thermal shock resistance:**
 - the ability of a material to be rapidly cooled and not fracture
 - is proportional to $\frac{\sigma_f k}{E \alpha_\ell}$



Bi Metallic Strip



A **bimetallic strip** is composed of two dissimilar metals joined together, usually in the form of two strips or two ribbons.


The two metals are specifically dissimilar in terms of their electrical conductivity, thermal conductivity, and mechanical properties.

Bi Metallic Strip



- ❑ When the strip is exposed to heat, the two dissimilar metals expand at different rates,
- ❑ the resulting bending is utilized to determine the value of the temperature change.
- ❑ This simplicity makes the bimetallic strip an ideal component for a wide variety of applications.


Bi Metallic Strip








Coefficient of Linear Thermal Expansion Change in Temperature

$$\Delta L = \alpha L \Delta T$$



Change in Length Original Length



Bi Metallic Strip



Bi Metallic Strip




$$\Delta L = \alpha L \Delta T$$

Coefficient of Linear Thermal Expansion $\rightarrow \alpha$
 Change in Temperature $\rightarrow \Delta T$
 Change in Length $\rightarrow \Delta L$
 Original Length $\rightarrow L$

Material	Thermal Coefficient of Expansion Per °C	Modulus of Elasticity	
		psi	GN/m ²
Invar	1.7×10^{-6}	21.4×10^6	147
Yellow brass	2.02×10^{-5}	14.0×10^6	96.5
Monel 400	1.35×10^{-5}	26.0×10^6	179
Inconel 702	1.25×10^{-5}	31.5×10^6	217
Stainless-steel type 316	1.6×10^{-5}	28×10^6	193

Bi Metallic Strip



$$r = \frac{t\{3(1+m)^2 + (1+mn)[m^2 + (1/mn)]\}}{6(\alpha_2 - \alpha_1)(T - T_0)(1+m)^2}$$



where

- t = combined thickness of the bonded strip, m or ft
- m = ratio of thicknesses of low- to high-expansion materials
- n = ratio of moduli of elasticity of low- to high-expansion materials
- α_1 = lower coefficient of expansion, per $^{\circ}\text{C}$
- α_2 = higher coefficient of expansion, per $^{\circ}\text{C}$
- T = temperature, $^{\circ}\text{C}$
- T_0 = initial bonding temperature, $^{\circ}\text{C}$

Bi Metallic Strip

CURVATURE AND DEFLECTION OF BIMETALLIC STRIP. A bimetallic strip is constructed of strips of yellow brass and Invar bonded together at 30°C. Each has a thickness of 0.3 mm. Calculate the radius of curvature when a 6.0-cm strip is subjected to a temperature of 100°C.

$$r = \frac{t\{3(1+m)^2 + (1+mn)[m^2 + (1/mn)]\}}{6(\alpha_2 - \alpha_1)(T - T_0)(1+m)^2}$$



$$T - T_0 = 100 - 30 = 70^\circ\text{C}$$

$$m = 1.0$$

$$n = \frac{147}{96.5} = 1.52$$

$$\alpha_1 = 1.7 \times 10^{-6}^\circ\text{C}^{-1} \quad \alpha_2 = 2.02 \times 10^{-5}^\circ\text{C}^{-1}$$

$$t = (2)(0.3 \times 10^{-3}) = 0.6 \times 10^{-3} \text{ m}$$

$$r = \frac{(0.6 \times 10^{-3})[(3)(2)^2 + (1 + 1.52)(1 + 1/1.52)]}{6(2.02 - 0.17)(10^{-5})(70)(2)^2}$$

$$= 0.132 \text{ m}$$